

POTENTIAL HAZARDS OF QUICK OPENING CYLINDER VALVES USED WITH FIREFIGHTING GASES

Several accidents with quick opening valves installed on fire fighting system gas cylinders have been reported. In one case, a worker died; in other cases workers suffered bone fractures (shinbone, hand).

In all cases, the cause of the accidents was the unintended opening of the valve fitted to the gas cylinder during handling of the cylinder. The consequences were that the cylinders went out of control after the valve suddenly opened. This type of valve is used on cylinders containing carbon dioxide or gas mixtures in fire fighting systems. The cylinder valves referenced in this safety bulletin have different designs and are not commonly encountered. They require additional safety precautions when handling.

The handling of gas cylinders (during filling, storage and transport) equipped with this type of valve is only safe if the quick opening valves have a locking device for the opening lever or a gastight outlet seal cap (blanking nut) to prevent accidental release. If not, there is no protection against the unintended opening of the valve. See Figures 1 and 2 for an example of this type of valve and a typical locking device. Cylinders equipped with a quick opening valve without a locking device on the opening lever or a gastight outlet seal cap (blanking nut) at the outlet shall not be handled or accepted for filling.

During discharge or filling, the gas cylinders must always be secured from falling by a holding device, and the gas cylinders shall only be released from this device if a blanking nut is installed at the valve outlet and/or the opening lever is locked and secured. Note that these cylinders are commonly larger and heavier than the usual industrial gas cylinders, and special precautions might be required when connecting them to filling equipment and during handling.



© EIGA 2008 - EIGA grants permission to reproduce this publication provided the Association is acknowledged as the source

EUROPEAN INDUSTRIAL GASES ASSOCIATION AISBL

AVENUE DES ARTS 3 – 5 • B-1210 BRUSSELS

PHONE +32 2 217 70 98 - FAX + 32 2 219 85 14 - E-mail : info@eiga.eu - www.eiga.eu

Figure 1—Cylinder valve with valve closed and locking device engaged



Figure 2—Cylinder valve with locking device disengaged and valve open

As part of a programme of harmonisation of industry standards, this Safety Information has been prepared with input from regional gases associations and a similar publication will be issued by these associations.

DISCLAIMER

All technical publications of EIGA or under EIGA's name, including Codes of practice, Safety procedures and any other technical information contained in such publications were obtained from sources believed to be reliable and are based on technical information and experience currently available from members of EIGA and others at the date of their issuance.

While EIGA recommends reference to or use of its publications by its members, such reference to or use of EIGA's publications by its members or third parties are purely voluntary and not binding. Therefore, EIGA or its members make no guarantee of the results and assume no liability or responsibility in connection with the reference to or use of information or suggestions contained in EIGA's publications.

EIGA has no control whatsoever as regards, performance or non performance, misinterpretation, proper or improper use of any information or suggestions contained in EIGA's publications by any person or entity (including EIGA members) and EIGA expressly disclaims any liability in connection thereto.

© EIGA 2008 - EIGA grants permission to reproduce this publication provided the Association is acknowledged as the source